Bumpstop Mount Kit

Installation Instructions

Please check that the package contains the following:

- 2 Pcs. Polyamid bumpstop mounts
- 2 Pcs. Stainless steel bolts
- 4 Pcs. Stainless steel washers

Installation

Remove the old bumpstop mount, if there is anything left. Drill a approximately 8,3mm hole, don't forget to do some rust protection after drilling.

Now secure the mount as it is shown in the illustration below.

