



KILLER PRODUCTS
INGERSLEVSGADE 130, 4. sal, tv / 1705 COPENHAGEN V
WWW.KILLER-PRODUCTS.DK

TEL: +45 60350036
INFO@KILLER-PRODUCTS.DK

Steering Wheel Quick Release Kit Installation Instructions

Please check that the package contains the following:

- 1 Pc. Bottle of locking glue
- 1 Pc. Special made mini boss
- 1 Pc. Quick release adaptor
- 6 Pcs. Stainless steel bolts
- 2 Pcs. Wires
- 1 Pc. Large earth washer

Installation

First make sure the wheels are pointing straight forward.

Unscrew your old steering wheel.

Loosen the 6 Stainless steel bolts and remove the quick release from the boss.

Mount the mini boss on the steering shaft with the blinker tap (black plastic) at 3 o'clock.

Fasten the big nut good– don't forget the washer.

Now connect the wire from the bottom part of the quick release and position it with the security button where you can reach it when the steering wheel is mounted.

Remember to put the locking glue onto the 6 bolts and make sure you tighten the bolts good without destroying them.

Position the big earth washer and connect one of the wires to it.
If the horn sounds please use the other connector.

Now mount and fasten your steering wheel and use locking glue on the bolts as well.

Connect the remaining wire to your horn button and press the button in place.

Please ensure that you have fastened all the bolts before driving!

Please respect the local law regarding detachable steering wheels, we can not take any responsibility for your use of this product.